

Sampling

Mechanical samplers "PNS"

■ Application

Aluminium sample spear for the easy manual sampling from vehicles or grain stores.

■ Sample taking

Insert the closed sample spear vertically or diagonally into the grain. By turning the handle, the sampling chambers gradually open up from the bottom to the top which guarantees an absolute average sample over the entire length. The sample spear has an opening at the top of the handle through which the entire sample flows out.

■ Cleaning

With an internal indent in the threaded top the sample spear can easily be pulled apart for cleaning purposes.



■ Technical Data

model:	PNS-84	PNS-88	PNS-88	PNS-88	pellets
length:	1,45m	2,0 m	2,5 m	3,0 m	1,3 m
diameter	38 mm	38 mm	38 mm	38 mm	50 mm
openings	8	8	8	8	8
weight	2,0 kg	2,5 kg	3,0 kg	3,5 kg	2,3 kg
article No.	1720 0300	1720 0310	1720 0315	1720 0318	1720 0320

Independent of the length of the spears, the openings are arranged in the lower part of approx. 1.10 m. A higher number of openings is not possible to guarantee the gradual opening from the bottom to the top.

We reserve the right to make technical modifications!

Can be used in all possible storage places of cereals and pellets, like granaries, storage halls, trucks, railway waggons and similar

■ Pfeuffer GmbH

P. O. Box 248
D-97305 Kitzingen

■ Phone +49- 93 21- 93 69 -0
Telefax +49- 93 21- 93 69 -50
e-mail info@pfeuffer.com

PFEUFFER
Mess- und Prüfgeräte

rational kornservice